

## DVR GUI switch between VGA and BNC



DVR support 2 display interface below:



NS/BR DVR can only have GUI on 1 video output. If you do not see GUI on your monitor, you can use 2 ways to change GUI output switch between BNC and VGA:

1. Press and hold REW button on front panel for 5 seconds, you will hear beep sound when GUI switch.
2. Press number "0" (zero) button on remote control, you will hear beep sound when GUI switch.