

# How to setup E-mail notification for Gmail




Step 1:

Right click USB mouse button to bring OSD menu and click “Main Menu” icon.



Step 2:

Select “Network”



Step 3:

Select “Email”



Step 4:

SSL: enable

SMTP port: 465


SMTP server: smtp.gmail.com

Sender e-mail: your e-mail address

Sender pwd: your e-mail address password

Receiver Email: receiver email address


Click “Apply” when finished



Step 5:

It will display message “Save finished!”

Click “OK”



Step 6:

Click “Email Test”




Step 7:

It will display message “Testing SMTP, Please wait”




Step 8:

If E-mail settings is correct, it will display message “Email Tested Succeeded!”



Step 9:

If E-mail settings is correct, it will display message “Authentication failed! Invalid username or password!”



Step 10:

Go to “Alarm” and enable “Send Email”




Step 11:


Go to “Advanced” → ”Events”.

User can also enable E-mail alert for Disk No Space, Disk Error, Video Loss.

Step 12: User can login to Gmail to check e-mail alert.



Step 13: This is motion email example.



Step 14: This is video loss email example.

