

1. Make sure your camera and computer are connected to the same router.
2. Insert the supplied CD to your computer's CD drive. Click **IPC Search**.
3. The program lists the camera by IP address. Double-click on the camera's IP address field.

4. Enter the user name & password of IP cameras. Default user name & password are as below. Click **Login**.
User name: admin
Password: 123456

5. Go to **Wifi** tab (Parameter > Network > Wifi), and click **Search** to search for wireless router. Click on the router name and enter the wireless router's password. Click **Apply**.

6. Disconnect the RJ45 Ethernet cable from the camera.
7. Reboot QRT-303.