

QRT-502 AP connection Mode

When your QRT-502 is failed to connection via SMART LINK mode (default), we conjecture that, there is an incompatibility issue with your wireless router and SMART LINK, when this happens, we suggest you switch connection mode from SMART LINK to AP.

- Switch QRT-502 to AP Mode :


Before switching, please reset QRT-502 (see video guide for reset:

<https://www.youtube.com/watch?v=FENJGdE-vIY&feature=youtu.be>).


Using a pin tool, insert and hold in the reset hole for 5-6 seconds, when the blue status LED starts blinking with a second interval, it means QRT-502 is switched to AP mode and ready for connection setup.

- Connection Setup for Smartphone/Tablet :


Step 1: Switch your smartphone / tablet to Wi-Fi mode, search Wi-Fi network, and the SSID of QRT-502 (IPCAM-AP-00XXXX-XXXX) will show up on the list.




Step 2 : Configure the SSID of QRT-502 (IPCAM-AP-00XXXX-XXXX) as your Wi-Fi network AP (no password required).




Step 3: Make sure your smartphone / tablet is connected with QRT-502 (IPCAM-AP-00XXXX-XXXX).




Step 4: Open App **KViewCam** on your smartphone / tablet.




Step 5: Click “Add new camera” .




Step 6: Click “Search” .





Step 7: Select “QRT-502 (KGCG-XXXXXX-XXXXX)” .




Step 8: Enter the default password: **admin** → Click “Done” .




Step 9: Make sure your QRT-502 is online → Click “” to set up WiFi setting.



Step 10: Select “WiFi Setting” .



Step 11: Click “Search WiFi” → select the wireless router (SSID) you want to connect.



Step 12: Enter the password of wireless router (SSID) → Click **“Done”** .



Step 13: After the **WiFi Setting** is done, the camera will automatically boot up, please wait...



Please wait for 10-15 seconds until the camera sounds **“Ding-Dong- Ding-Dong”** , it means the WiFi setting is successful; meanwhile, the blue status LED will stop blinking.